



How to Update the Firmware


1. NOTE THAT ALL FILES ON THE BRICK WILL BE DELETED
2. Open LEGO MINDSTORMS NXT and select Tools/Update NXT Firmware




3. Select On Line Updates : Check (You will need internet access)




4. Your web browser will open and show the following screen. Select firmware then Firmware 1.29. Then click on Downloads



5. Instructions will pop up with a button to get the download. Download the file and then unzip it as directed...



6. When the file has been unzipped into ...Program Files\LEGO Software\LEGO MINDSTORMS NXT\Firmware, you will see version 1.29 appear when you go back to Tools/Update NXT Firmware window



7. Select LEGO_MINDSTORMS_NXT_Firmware_V1.29. Ensure your NXT Brick is plugged into the PC and turned on and click on Download. There will be a few beeps and clicks and eventually the three progress bars will fill and the brick is now running the latest (for now) firmware. **NOTE ALL FILES THAT WERE ON THE BRICK WILL BE DELETED**